



NOTES:

1. Place minimum of four inches of dirt over the key point.
2. Insert the ball marker over the desired point. Don't bury it more than four feet deep. It cannot re-radiate the locator's signal more than four feet from the locator.
3. Handfill a minimum of six inches of soil over the marker.
4. Backfill hole.

C.U. - BMARK
(76.0250)

REF: 3M Company

NTS

Date: 6-3-2013